



VF-1A Assembly



1



Connect liftarm to pin

2



3



4



5

